Enlarge to 12X12

Tape this flap into the back end of the bottom with strong tape top cover with cellephene